

■ INSTRUCTIONS

ATTENTION

- **This appliance is not intended for use by persons (including children) with reduced physical, sensor or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.**
- **Children should be supervised to ensure that they do not play with the appliance.**


CONTAINS BATTERY

Battery must be recycled or disposed of properly.

CORRECT DISPOSAL

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

PARTS DESCRIPTION



ACCESSORIES NAME



Illuminating light for hard to see hairs



Shaving head



Cleaning brush



Epilation head

Adapter
(100-240 V 50/60 HZ 3 W)

Clipper head

INSTRUCTIONS FOR USE

For ultimate results, please take a warm bath or shower before you use your Callus Remover & Epilator & Shaver, it will help the process more comfortable.

Charge 16 hours when charging for the first time. The unit can also be used with the plug connected to the unit when it is not fully charged. After removing the plastic insert, the switch can then be slid up or down for the selected speed.




Insert plug into base of unit.



The red indicator lights when it is plugged into an electric outlet.



After charging for 16 hours, remove the plug from the base of unit.




Remove the plastic protective cover. Remove the plastic Insert at the top of the switch.




The unit has 2 speeds.

-  Low speed for fine hair.
-  High speed for coarse hair.



Hold the unit in you palm, at a 90 angle, so the logo is facing away from you. You do not need to apply pressure, just touch the surface of the skin.



Use short, quick, brush like or sweeping motions in the direction of hair growth.



Make sure to hold the skin surrounding the area you are removing hair from taut. Keep your leg extended when removing hair from behind the knees.



May be used for the bikini area (hold the skin-taut with one hand).



Can be used to remove individual hairs from the upper lip and chin area.



May be used to remove hair from underarms (extend your arm so the skin is held taut).



Using callus remover for beautiful, smooth feet, and remove dead skin on other area.



To clean: Remove the head of the unit by gently pressing on the release button on the side of the unit.




Gently brush the tweezer heads to remove any hair.



Replace the head.



Light illuminates easy to see hairs (light comes on when you turn the unit ON).



Warning:

Please don't stop callus remover head by finger at two sides, or we will not take responsibility for any damage.